

## INCLUDED HARDWARE:

4 *Fibre Washers* 

2 *Spring Washers* 

2 *Nylon Fasteners* 

1 *Tearbar*

## WARRANTY

Egan Visual Inc. warrants the construction and finish of this product for normal and reasonable use for the period of five (5) years from the date of invoice. This warranty does not apply to defects resulting from lack of normal maintenance, improper cleaning or negligence.

Comments  
— or —  
Questions?

**CALL US!**

CANADA: 1-800-263-2387  
USA EAST: 1-800-263-2387  
USA WEST: 1-800-826-1778

email: [installations@egan.com](mailto:installations@egan.com)  
[www.egan.com](http://www.egan.com)

Reference #024H231 rev 1-07/04:5M

©Egan Visual, Inc. 2004

Flipchart  
Tearbar

**INSTALLATION**



The Leader in Visual Systems  
...and more



The Leader in Visual Systems  
...and more



The Leader in Visual Systems  
...and more

**TOOLS REQUIRED:**

# Slot Screwdriver

**NOTE:**

Handle the Tearbar edges with care.

**PICTURE A**

1. Place fiber washer on fastener screw. Insert thru Tearbar. Place fiber washer then spring washer onto screw fastener.
2. Place assembly into threaded holes and push in while turning clockwise as shown. Do not over tighten.

**PICTURE B**

3. Next with the Tearbar remaining in the upper position place the Flipchart Pad onto the fastener heads.

**PICTURE C**

4. Carefully slide the Tearbar vertically into the lowered and locked position and your Flipchart pad is ready to use.

