THE   TecTern   WILL ARRIVE IN ITS LOWERED
AND LOCKED POSITION. INCLUDED IN THE
BAG, ATTACHED TO THE TOP, ARE A CD
WITH DRIVERS FOR THE TOUCH DISPLAY
MONITOR AND KEYS TO ACCESS THE UNIT.

TO OPEN THE *TecTern*:

1. Unlock the front door using the included keys.

2. Open the top door by lifting it from the front
edge, then folding it back to rest on the top
surface.

3. Pull the front door from its closed position and
rotate it under the bottom of the   TecTern   .
It will be held in place magnetically.

TO LOCK THE *TecTern* FOLLOW THE
ABOVE STEPS IN REVERSE ORDER.

EGAN EGAN VISUAL INC.
300 Hanlan Road
Woodbridge, ON L4L 3P6

Tel: (905) 851-2826   Fax : (905) 851-3426
(800) 263-2316   Email : evc@egan.com

EGAN TecTern

PRODUCT CODE: TMTM	MATERIAL: --	DRAWN BY: G.H	DATE DRAWN: 17/06/2011
RMC: --	FINISH: --	APPROVED BY: J.W	DATE APPROVED: 17/06/2011
NC CODE: --	DO NOT SCALE DRAWING	SCALE: NTS	UNITS: INCHES	SHEET: 1 OF 3

A

GENERAL TOLERANCE: ± 0.010
UNLESS SPECIFIED OTHERWISE

DRAWING NO:

INSIDE THE *TecTern* ARE:

1. Touch Screen Display - with a tilt that can be adjusted by grabbing the two sides of the monitor and moving it to the desired angle.

2. Pull-Out Laptop Tray - can accommodate devices up to 1.8"(h)x19"(w)x12.25"(d)

3. Height Adjustment Switch - which only functions when the TecTern is powered (see pg.3)

Thumb Screws

TO GAIN ACCESS TO THE INTERNAL STORAGE AND COMPONENTS, THE TOP DOOR ASSEMBLY NEEDS TO BE REMOVED.

1. Remove the 2 thumb screws which lock the door assembly in position.

2. Slide the door assembly aprox. 1"- 2" forward and lift up, off of the *TecTern* crown.

EGAN TecTern

A

PRODUCT CODE: TMTM	MATERIAL: --	DRAWN BY: G.H	DATE DRAWN: 17/06/2011
RMC: --	FINISH: --	APPROVED BY: J.W	DATE APPROVED: 17/06/2011
NC CODE: --	DO NOT SCALE DRAWING	SCALE: NTS	UNITS: INCHES	SHEET: 2 OF 3
GENERAL TOLERANCE: ± 0.010 UNLESS SPECIFIED OTHERWISE	DRAWING NO:		

2

1

INSIDE THE BACK STORAGE ARE:

1. Electrical Power Bar

2. Pass Through Holes - to access the
lower storage bucket

3. VGA Video Splitter - see diagram below

Touch
Display

Projector
VGA

VGA
SPLITTER

To Laptop

1

3

4

2

EXTERNAL WIRING:

1. Run the a powered extension cord into
one of the lower bucket openings and
connect it to the power bar.

2. Bring *TecTern* to its full height and
remove the cable retaining panel.

3. Pass cables (ie: Projector VGA,
Network + Audio) through the lower
bucket opening and position within
TecTern as required. Leave any excess
wire in the lower bucket.

4. Run the exposed cables along the
presenter side of the post and replace the
cable retaining panel.

EGAN VISUAL INC.
300 Hanlan Road
Woodbridge, ON L4L 3P6

Tel: (905) 851-2826   Fax : (905) 851-3426
(800) 263-2316   Email : evc@egan.com

EGAN TecTern

A

PRODUCT CODE: TMTM	MATERIAL: --	DRAWN BY: G.H	DATE DRAWN: 17/06/2011
RMC: --	FINISH: --	APPROVED BY: J.W	DATE APPROVED: 17/06/2011
NC CODE: --	DO NOT SCALE DRAWING	SCALE: NTS	UNITS: INCHES	SHEET: 3 OF 3
GENERAL TOLERANCE: ± 0.010 UNLESS SPECIFIED OTHERWISE	DRAWING NO:		